

BONECO
healthy air

TRADITION SINCE 1956
 A SWISS COMPANY

P340 MANUAL



READ AND SAVE THESE INSTRUCTIONS

INSTRUCTIONS FOR USE BONECO P340

OVERVIEW AND PART NAMES



- 1 Front cover
- 2 Pre-filter
- 3 Filter A341
- 4 BONECO P340
- 5 Keypad with displays

TABLE OF CONTENTS

Overview and part names	14
Items included	16
Technical data	16
Start-up	17
Front cover and replacement filter	18
Magnetic front cover	18
Replacement filters	18
Indicators on the display	19
Clearing the filter warning	19
Basic functions	20
“Auto” mode	20
Air quality indicator	20
Manually controlling the fan level	20
Ionizer and timer function	21
Ionizer	21
Timer function	21
Setting the OFF timer	21
Cleaning and maintenance	22
Replacing the filter	22
Cleaning the pre-filter	22

INSTRUCTIONS FOR USE FOR BONECO P340

DEAR CUSTOMER,

Congratulations on your purchase of the BONECO P340. The extremely efficient air purifier is equipped with a high-quality filter which rids the air of odors as well as dust, pollen and dirt particles. The filter also effectively alleviates many forms of discomfort caused by allergies. This also includes hay fever or allergic reactions to household dust and mite excrement.


The BONECO P340 is designed for easy, fully automated operation. The smart control system ensures that the noise level remains as low as possible. Thanks to the integrated timer, the appliance also runs whenever you are not at home. This means you can always come home to an optimal room climate.

We hope you enjoy your new BONECO P340 air purifier!

ITEMS INCLUDED



BONECO P340 with country-specific power cable



Filter A341

TECHNICAL DATA*

Type designation	BONECO P340
Mains voltage	220–240 V, 50 Hz
Power consumption	46 W
Operating noise level	57 dB(A)
Cleaning output (CADR)	210 m ³ /h (177 CFM)
Air flow	300 m ³ /h (177 CFM)
Dimensions L×W×H	206×336×527 mm
Weight (empty)	5.3 kg / 6.3 kg

* Subject to change

START-UP

**1**

Remove the magnetically fixed front cover.

**2**

Take off the pre-filter.

**3**

Take out the filter and remove the protective foil.

**4**

Insert the filter back into the holder (note the markings).

**5**

Put the pre-filter back on.

**6**

Reattach the front cover.

FRONT COVER AND REPLACEMENT FILTER

MAGNETIC FRONT COVER


The front cover of the BONECO P340 is held on by magnets. The air purifier is not switched on if the front cover is missing or positioned incorrectly.

REPLACEMENT FILTERS

You can obtain replacement filters from your BONECO specialist dealer or in the online store at:

www.shop.boneco.com.

INDICATORS ON THE DISPLAY



All displays on the appliance

Indicators	Meaning	
	Ionizer is switched on or off	21
	Timer function (1, 2, 4 or 8 hours)	21
	Display of air quality (green, orange, red)	20
	AUTO mode and fan level	20
	Filter used up, replace	22

CLEARING THE FILTER WARNING

The “Filter” display  remains illuminated after the filter has been replaced. Press and hold the -button for five seconds to hide the display. This also resets the counter for the new filter at the same time.

BASIC FUNCTIONS

The BONECO P340 can easily be adapted to your needs. During start-up of the appliance, the basic setting of the fan level is in automatic mode (AUTO MODE).

“AUTO” MODE

In the mode *AUTO* the fan level is automatically regulated depending on the air quality. After the appliance is switched on for the first time, it runs for the first five minutes at the lowest fan level “L”.

AIR QUALITY INDICATOR

The air quality is measured by the built-in sensor and is visualized by different colors on the “air” display.



When the appliance is switched on, it takes around five minutes until the sensor has measured the current air quality. The “Air” display flashes during this period .

Please note that the measured values may change depending on the size of the room and the position of the appliance.

The sensor registers the smallest dirt particles and gases. They include house dust, pollen, gases such as tobacco smoke, organic compounds and odors.

MANUALLY CONTROLLING THE FAN LEVEL

The fan level of the BONECO P340 can be manually controlled.

Push the  button several times until the desired fan level is attained.

IONIZER AND TIMER FUNCTION

IONIZER

The ionizer is activated by pressing the “ION” button  once. Pressing the button again switches off the ionizer.

TIMER FUNCTION

The timer function lets you determine how long the BONECO P340 should run before it switches off automatically (OFF timer).

SETTING THE OFF TIMER

1. Switch on the BONECO P340 by pressing the  button.
2. Select the desired operating setting and the desired comfort mode.
3. Press the  button once.
4. Use the  button to set how long the appliance operates (1, 2, 4 or 8 hours).

The appliance runs for the specified period and is then switched off.

5. In order to end the timer prematurely, keep the -button pressed until the timer switches off and the display  is indicated. Alternatively, you can switch off the BONECO P340 using the  button.

CLEANING AND MAINTENANCE

REPLACING THE FILTER

The filter is used up when the “filter” indicator  is illuminated. The filter must now be replaced to continue to ensure optimal air purification.

The procedure for replacing the filter corresponds to the figures on page 17.

1. Replace the filter in accordance with the instructions on page 17.
2. Press the -button for 5 seconds until the indicator  goes out.

CLEANING THE PRE-FILTER

The pre-filter prevents excessive dust accumulation from getting inside the BONECO P340.

1. Clean the pre-filter under running water or using a vacuum cleaner.



2. Allow the pre-filter to dry completely before you re-insert it.

 Do not use alcohol or corrosive cleaning agents for cleaning.